

For: OPEL®-VAUXHALL® (also for CHEVROLET®-DAEWOO®)



HU100R02



Make	Model	Chassis	From	To	Blade
Chevrolet®-Daewoo®	Aveo	T300 (TA, TF)	2011		HU100
Chevrolet®-Daewoo®	Cruze	J300-PD (JA, JF)	2008	2014	HU100
Chevrolet®-Daewoo®	Orlando	J309 (KL1YF)	2011	2015	HU100
Chevrolet®-Daewoo®	Spark	M400	2015		HU100
Opel®-Vauxhall®	Adam		2013		HU100
Opel®-Vauxhall®	Astra	J	2009	2015	HU100
Opel®-Vauxhall®	Cascada		2013		HU100
Opel®-Vauxhall®	Corsa	E	2014		HU100
Opel®-Vauxhall®	Insignia	A	2008	2017	HU100
Opel®-Vauxhall®	Mokka		2012		HU100
Opel®-Vauxhall®	Zafira	C	2013		HU100



HU100R23



Make	Model	Chassis	From	To	Blade
Opel®-Vauxhall®	Astra	K	2016		HU100

For: PSA® (CITROËN®, FIAT®, LANCIA®, PEUGEOT®, TOYOTA®)



VAR16



Make	Model	Chassis	From	To	Blade
Citroën®	Berlingo	B9	2009	2014	VA2
Citroën®	C2	MY60 VF7J	2005	2009	VA2
Citroën®	C3	A51 VF7F	2005	2009	VA2
Citroën®	C3	A51 VF7S	2009	2016	VA2
Citroën®	C3 Picasso	A58	2008	2017	VA2
Citroën®	C3 Pluriel	VF7F	2005	2009	VA2
Citroën®	C4 Picasso		2006	2013	HU83
Citroën®	C4 Picasso		2006	2013	HU83
Citroën®	C5	X9 VF7R	2006	2011	HU83
Citroën®	C8	U65 VF7B	2005	2009	HU83
Citroën®	C8	V3 VF7E	2009	2014	HU83